



Esiporaus ruuveille
Förborrning för skruvarna
Pilot hole for the screw

HUOM. Upotusmitat ovat ohjeellisia.
The mortise measures are normative.

900371-A